ISR socket
Clutch switch
High/Low beam switch
Turn ligh switch
Flasher
Horn switch
Horn
Frontbrake switch
Rear brake switch
Light switch
Flameou switch
Start switch
Ignition switch
Sidestand switch
TCS switch
Trigger
Magnetic motor
Rectifier
Wire key protection
Start replay
Battery
Start motor
Wire safety protection
Gear switch
Speedometer
N gear
1 gear
2 gear
3 gear
4 gear
Oil pressure indicate
TPS signal
Always On
ECU malfunction indicate
Left turn output signal
Right turn output signal
High beam signal
Wheel speed sensor
RPM signal
Fuel level sensor
Speedometer water tem signal
ABS indicate
EFI Diagnostic connector
CAN-H
CAN-L
K wire
Tail light/brake light
LED
High beam(LED)
Low beam(LED)
Front position light(LED)
Right turn light(LED)
Left turn light(LED)
GN fuse:15A
Light fuse:20A
ECU fuse:15A
Fan fuse:20A
ABS ECU power fuse:10A
ABS motor fuse:20A
Rear wheel speed sensor
Front wheel speed sensor
ABS BOSCH
Water temperature sensor
Fuel level sensor
Jump sensor
Two-in-one sensor
Throttle position sensor
Oil pressure sensor
Battery power
Fan motor
Fan relay
Main relay
Fuel pump relay
Fuel pump
Stepper motor
Cylinder1 ignition
Cylinder2 ignition
Cylinder1 injection
Cylinder2 injection
Oxygen sensor1
Oxygen sensor2

Code	B	B	O	W	I	W	O	GB	V	BN	Lg	Gr	P
Color	yel	black	green	redwy	blue	white	organg	light blue	purple	brown	Light green	gre	pink

BD250-16A

Electrical circuit diagram